Operating Instructions for
Golfzilla & Golfoptomus

Contents:

- Inflatable Golfzilla/ Golfoptomus Air target
- Air Blower
- 4 Stakes
- 6 Ropes
- 1 Extension Cord

Setting Up:

- Take Inflatable out of blue carrying bag
- Lay out flat
- Identify long "air-in" hole with ties
- Do not lay Inflatable on rocks, concrete, branches, or any other hard or sharp ground
- Make sure Inflatable is not laying upside down but pointing the correct direction
- Tie "air-in" hole around mouth of blower and tie tight
- Plug blower into extension cord and into outlet
- "On" switch in on side of blower
- As target inflates, check that all zippers on feet and tail are zipped closed
- Locate grommet on legs, feet, and sides of body. Tie rope around grommet and stakes. Stake in ground.
- Set up away from trees or other sharp objects that could puncture fabric if wind blows Golfzilla over

In Use:

- Do not hit golf balls at inflatables
- Do not throw golf clubs at inflatables
- Do not jump on or tackle inflatables
- Use only Birdies or SNAG balls when hitting at inflatables

Taking Down:

- Turn off Blower
- Untie "air in" hole from blower
- Unzip holes in tail and feet
- Let inflatable naturally fall down and release air
- Being very gentle, start from the head and arms and slowly push the air out towards the feet and tail
- Once all the air is out, bring inflatable together and start putting parts of fabric into the blue carrying bag. This may take a few minutes and needs to be done on soft ground without golf shoe spikes on the fabric.
- Carefully zip the bag closed making sure to not zip inflatable fabric into zipper

Damage:

- Any damage is the responsibility of the renter

Signature:_____ **Date:**_____